


## Programming the RCA RCR504BR IR Remote Control



- 1) Press and hold the Code Search key until the indicator light turns on.
- 2) Press and release the TV key—the indicator light blinks and then remains lit.
- 3) Enter the four digit code 1758 using the numeric keypad. After the code is entered, the indicator light turns off. Note: if the indicator light blinks multiple times, you've entered an invalid code. Start from step 2 again. The remote control is ready to read or edit the lantern.

# CR

CONTROL SYSTEMS INC.

Rivermill Commercial Center  
85 Mechanic Street, Suite C1-S1  
Lebanon, NH 03766 USA  
Phone: 603-727-9149  
[www.crconsys.com](http://www.crconsys.com)