

C-R Control Systems, Inc.

Rhythm Versions 501 (500), 505

For Programmable Flasher Models 8920-03, 8930-03, 8920P-03, 8930P-03, 9010-03

Programmable Flasher Models

8920-03	Aluminum Housing Lampchanger only
8930-03	Aluminum Housing Dual Filament and Lampchanger
8920P-03	Plastic Housing Lampchanger only
8930P-03	Plastic Housing Dual Filament and Lampchanger
8920PCG-03	Plastic Housing Lampchanger only, no Synchronization
9010-03	Plastic Housing Lampchanger, Dual Filament, Programmable Output Voltages

Versions 501 (500), 505

*Remove cap or cover to expose switches.

*When replacing cover be sure seal ring or gasket is seated properly.

*Flasher must be disconnected from power source before changing rhythm.

*Switch position OFF = 0 ON = 1

*For external *infinite* programming of rhythms 01 to 04 using Programmer Model 9400, set switches as shown for each of these rhythms before programming.

*Internally programmable with 10 internal switches which control:

<u>Switch</u>	<u>Flasher Models</u>	<u>Function</u>															
1-8	All Models	Up to 256 rhythm selection + Infinite Rhythm Selection															
9	Models 8930-03, 8930P-03 9010-03 No function for models 8920-03, 8920P-03 8920PCG-03	Lampchanger/Dual Filament-Regulated Voltages OFF - 12V regulated first output (L terminal) No regulation second output If rhythm is set to FIXED, second output (F terminal) will pulse to operate solenoid. ON - 10.3V regulated first and second outputs (L and F terminals) If rhythm is set to FIXED, second output will be FIXED.															
10	All Models No function for model 8920PCG-03	Daylight Control and Synchronization Function OFF - When Daylight Control turns flasher off - sync pulse will be ignored during daylight period. Flasher will turn on and off at dusk and dawn separately. ON - Sync pulse will cause flasher to continue to flash in sync during daylight period. Flasher will turn on and off at dusk and dawn in unison. C_R "True Sync" system.															
11-12	9010-03	4 regulated Voltages as follows: <table><thead><tr><th><u>SW</u></th><th><u>24V</u></th><th><u>12V</u></th><th><u>10.3V</u></th><th><u>6.2V</u></th></tr></thead><tbody><tr><td>11</td><td>OFF</td><td>ON</td><td>OFF</td><td>ON</td></tr><tr><td>12</td><td>OFF</td><td>ON</td><td>ON</td><td>OFF</td></tr></tbody></table>	<u>SW</u>	<u>24V</u>	<u>12V</u>	<u>10.3V</u>	<u>6.2V</u>	11	OFF	ON	OFF	ON	12	OFF	ON	ON	OFF
<u>SW</u>	<u>24V</u>	<u>12V</u>	<u>10.3V</u>	<u>6.2V</u>													
11	OFF	ON	OFF	ON													
12	OFF	ON	ON	OFF													

RH SW	1 2 3 4 5 6 7 8	RHYTHM	FL1	EC1	FL2	EC2	FL3	EC3	FL4	EC4	FL5	EC5
1	0 0 0 0 0 0 0 0	EXTERNAL										
2	1 0 0 0 0 0 0 0	EXTERNAL										
3	0 1 0 0 0 0 0 0	EXTERNAL										
4	1 1 0 0 0 0 0 0	EXTERNAL										
5	0 0 1 0 0 0 0 0	FL1S	0.25	0.75								
6	1 0 1 0 0 0 0 0	FL1.5S	0.50	1.00								
7	0 1 1 0 0 0 0 0	FL2S	0.30	1.70								
8	1 1 1 0 0 0 0 0	FL2S	0.50	1.50								
9	0 0 0 1 0 0 0 0	FL2S	0.20	1.80								
10	1 0 0 1 0 0 0 0	FL2.5S	0.30	2.20								
11	0 1 0 1 0 0 0 0	FL2.5S	0.50	2.00								
12	1 1 0 1 0 0 0 0	FL3S	0.30	2.70								
13	0 0 1 1 0 0 0 0	FL3S	0.50	2.50								
14	1 0 1 1 0 0 0 0	FL3S	1.00	2.00								
15	0 1 1 1 0 0 0 0	FL3S	0.40	2.60								
16	1 1 1 1 0 0 0 0	FL3S	0.75	2.25								
17	0 0 0 0 1 0 0 0	FL4S	0.40	3.60								
18	1 0 0 0 1 0 0 0	FL4S	0.50	3.50								
19	0 1 0 0 1 0 0 0	FL4S	1.00	3.00								
20	1 1 0 0 1 0 0 0	FL4S	0.30	3.70								
21	0 0 1 0 1 0 0 0	FL5S	0.50	4.50								
22	1 0 1 0 1 0 0 0	FL5S	1.00	4.00								
23	0 1 1 0 1 0 0 0	FL6S	0.50	5.50								
24	1 1 1 0 1 0 0 0	FL6S	0.60	5.40								
25	0 0 0 1 1 0 0 0	FL6S	1.00	5.00								
26	1 0 0 1 1 0 0 0	FL6S	0.30	5.70								
27	0 1 0 1 1 0 0 0	FL7.5S	1.00	6.50								
28	1 1 0 1 1 0 0 0	FL8S	1.00	7.00								
29	0 0 1 1 1 0 0 0	FL8S	0.50	7.50								
30	1 0 1 1 1 0 0 0	FL10S	0.50	9.50								
31	0 1 1 1 1 0 0 0	FL10S	1.00	9.00								
32	1 1 1 1 1 0 0 0	FL10S	2.00	8.00								
33	0 0 0 0 0 1 0 0	FL12S	1.20	10.80								
34	1 0 0 0 0 1 0 0	FL12S	1.00	11.00								
35	0 1 0 0 0 1 0 0	FL15S	1.00	14.00								
36	1 1 0 0 0 1 0 0	FL15S	0.50	14.50								
37	0 0 1 0 0 1 0 0	FL15S	2.00	13.00								
38	1 0 1 0 0 1 0 0	FL15S	3.00	12.00								
39	0 1 1 0 0 1 0 0	FL(2)3S	0.50	0.50	0.50	1.50						
40	1 1 1 0 0 1 0 0	FL(2)4S	0.50	0.50	0.50	2.50						
41	0 0 0 1 0 1 0 0	FL(2)4S	0.30	0.70	0.30	2.70						
42	1 0 0 1 0 1 0 0	FL(2)5S	0.40	0.60	0.40	3.60						
43	0 1 0 1 0 1 0 0	FL(2)5S	0.50	1.00	0.50	3.00						
44	1 1 0 1 0 1 0 0	FL(2)5S	0.30	0.90	0.30	3.50						
45	0 0 1 1 0 1 0 0	FL(2)5S	0.25	1.00	0.25	3.50						
46	1 0 1 1 0 1 0 0	FL(2)5S	0.75	0.75	0.75	2.75						
47	0 1 1 1 0 1 0 0	FL(2)6S	1.00	1.00	1.00	3.00						
48	1 1 1 1 0 1 0 0	FL(2)6S	0.50	1.00	0.50	4.00						
49	0 0 0 1 1 0 0 0	FL(2)6S	0.30	0.70	0.30	4.70						
50	1 0 0 0 1 1 0 0	FL(2)6S	0.30	0.90	0.30	4.50						
51	0 1 0 0 1 1 0 0	FL(2)6S	0.50	0.50	0.50	4.50						
52	1 1 0 0 1 1 0 0	FL(2)7S	0.50	1.50	0.50	4.50						
53	0 0 1 0 1 1 0 0	FL(2)8S	0.50	1.00	0.50	6.00						
54	1 0 1 0 1 1 0 0	FL(2)8S	0.50	1.50	0.50	5.50						
55	0 1 1 0 1 1 0 0	FL(2)8S	1.00	1.50	1.00	4.50						
56	1 1 1 0 1 1 0 0	FL(2)8S	1.00	2.00	1.00	4.00						
57	0 0 0 1 1 1 0 0	FL(2)9S	1.00	2.00	1.00	5.00						
58	1 0 0 1 1 1 0 0	FL(2)10S	0.50	1.00	0.50	8.00						
59	0 1 0 1 1 1 0 0	FL(2)10S	0.50	1.50	0.50	7.50						
60	1 1 0 1 1 1 0 0	FL(2)10S	1.00	1.50	1.00	6.50						
61	0 0 1 1 1 1 0 0	FL(2)10S	1.00	1.00	1.00	7.00						
62	1 0 1 1 1 1 0 0	FL(2)10S	0.40	2.00	0.40	7.20						
63	0 1 1 1 1 1 0 0	FL(2)10S	0.50	2.00	0.50	7.00						
64	1 1 1 1 1 1 0 0	FL(2)10S	1.00	2.00	1.00	6.00						
65	0 0 0 0 0 1 0 0	FL(2)10S	1.50	1.50	1.50	5.50						
66	1 0 0 0 0 1 0 0	FL(2)10S	0.40	0.60	0.40	8.60						
67	0 1 0 0 0 1 0 0	FL(2)12S	0.50	1.00	0.50	10.00						
68	1 1 0 0 0 1 0 0	FL(2)12S	1.00	2.00	1.00	8.00						
69	0 0 1 0 0 1 0 0	FL(2)15S	0.40	1.60	0.40	2.60						
70	1 0 1 0 0 1 0 0	FL(2)15S	1.00	2.00	1.00	11.00						
71	0 1 1 0 0 1 0 0	FL(2)15S	1.00	3.00	1.00	10.00						
72	1 1 1 0 0 1 0 0	FL(2)15S	2.50	2.50	2.50	7.50						
73	0 0 0 1 0 0 1 0	FL(2)20S	2.00	2.00	2.00	14.00						
74	1 0 0 1 0 0 1 0	FL(2+1)6S	0.30	0.40	0.30	1.20	0.30	3.50				
75	0 1 0 1 0 0 1 0	FL(2+1)6S	0.50	0.50	0.50	1.50	0.50	2.50				
76	1 1 0 1 0 0 1 0	FL(2+1)8S	0.50	0.50	0.50	1.50	4.50					
77	0 0 1 1 0 0 1 0	FL(2+1)10S	0.50	0.70	0.50	2.10	0.50	5.70				
78	1 0 1 1 0 0 1 0	FL(2+1)10S	0.50	0.50	0.50	1.50	0.50	6.50				
79	0 1 1 1 0 0 1 0	FL(2+1)12S	0.80	1.20	0.80	2.40	0.80	6.00				
80	1 1 1 1 0 0 1 0	FL(2+1)12S	0.30	0.70	0.30	2.70	0.30	7.70				
81	0 0 0 0 1 0 1 0	FL(2+1)12S	0.50	0.50	0.50	2.50	0.50	7.50				
82	1 0 0 0 1 0 1 0	FL(2+1)12S	1.00	1.00	1.00	3.00	1.00	5.00				
83	0 1 0 0 1 0 1 0	FL(2+1)15S	1.00	2.00	1.00	5.00	1.00	5.00				
84	1 1 0 0 1 0 1 0	FL(2+1)15S	1.00	2.00	1.00	4.00	1.00	6.00				
85	0 0 1 0 1 0 1 0	FL(2+1)15S	0.50	0.50	0.50	0.50	1.50	11.50				
86	1 0 1 0 1 0 1 0	FL(2+1)15S	1.00	2.00	1.00	4.00	1.00	6.00				
87	0 1 1 0 1 0 1 0	FL(2+1)15S	0.40	0.50	0.40	0.50	1.20	12.00				
88	1 1 1 0 1 0 1 0	FL(3)5S	0.25	0.25	0.25	0.25	0.25	3.75				
89	0 0 0 1 1 0 1 0	FL(3)5S	0.20	0.30	0.20	0.30	0.20	3.80				
90	1 0 0 1 1 0 1 0	FL(3)5S	0.30	0.70	0.30	0.70	0.30	2.70				

RH SW	1 2 3 4 5 6 7 8	RHYTHM	FL1	EC1	FL2	EC2	FL3	EC3	FL4	EC4	FL5	EC5
91	0 1 0 1 1 0 1 0	FL(3)9S	0.50	1.50	0.50	1.50	0.50	4.50				
92	1 1 0 1 1 0 1 0	FL(3)10S	0.50	1.50	0.50	1.50	0.50	5.50				
93	0 0 1 1 1 0 1 0	FL(3)10S	1.00	1.00	1.00	1.00	1.00	5.00				
94	1 0 1 1 1 0 1 0	FL(3)10S	0.50	0.50	0.50	0.50	0.50	7.50				
95	0 1 1 1 1 0 1 0	FL(3)10S	0.30	0.70	0.30	0.70	0.30	7.70				
96	1 1 1 1 1 0 1 0	FL(3)10S	0.40	1.60	0.40	1.60	0.40	5.60				
97	0 0 0 0 0 1 1 0	FL(3)10S	0.75	1.25	0.75	1.25	0.75	5.25				
98	1 0 0 0 0 1 1 0	FL(3)11S	0.50	1.50	0.50	1.50	0.50	1.50	0.50	4.50		
99	0 1 0 0 0 1 1 0	FL(3)12S	0.80	1.20	0.80	1.20	0.80	7.20				
100	1 1 0 0 0 1 1 0	FL(3)12S	0.50	2.00	0.50	2.00	0.50	6.50				
101	0 0 1 0 0 1 1 0	FL(3)12S	0.30	1.70	0.30	1.70	0.30	7.70				
102	1 0 1 0 0 1 1 0	FL(3)12S	0.50	1.50	0.50	1.50	0.50	7.50				
103	0 1 1 0 0 1 1 0	FL(3)12S	1.00	2.00	1.00	2.00	1.00	5.00				
104	1 1 1 0 0 1 1 0	FL(3)13S	1.00	2.00	1.00	2.00	1.00	6.00				
105	0 0 0 1 0 1 1 0	FL(3)15S	0.50	1.50	0.50	1.50	0.50	10.50				
106	1 0 0 1 0 1 1 0	FL(3)15S	1.00	2.00	1.00	2.00	1.00	8.00				
107	0 1 0 1 0 1 1 0	FL(3)15S	0.50	2.00	0.50	2.00	0.50	9.50				
108	1 1 0 1 0 1 1 0	FL(3)15S	1.50	1.50	1.50	1.50	1.50	7.50				
109	0 0 1 1 0 1 1 0	FL(3)15S	0.75	1.25	0.75	1.25	0.75	10.25				
110	1 0 1 1 0 1 1 0	FL(3)20S	0.50	3.00	0.50	3.00	0.50	12.50				
111	0 1 1 1 0 1 1 0	FL(3)20S	2.00	2.00	2.00	2.00	2.00	10.00				
112	1 1 1 1 0 1 1 0	FL(3+1)23S	0.50	1.50	0.50	1.50	0.50	4.50	0.50	13.50		
113	0 0 0 0 1 1 1 0	FL(4)5S	0.20	0.80	0.20	0.80	0.20	0.80	0.20	1.80		
114	1 0 0 0 1 1 1 0	FL(4)10S	0.50	1.00	0.50	1.00	0.50	1.00	0.50	5.00		
115	0 1 0 0 1 1 1 0	FL(4)10S	0.40	1.40	0.40	1.40	0.40	1.40	0.40	4.20		
116	1 1 0 0 1 1 1 0	FL(4)10S	0.75	0.75	0.75	0.75	0.75	0.75	0.75	4.75		
117	0 0 1 0 1 1 1 0	FL(4)10S	0.50	1.50	0.50	1.50	0.50	1.50	0.50	3.50		
118	1 0 1 0 1 1 1 0	FL(4)12S	0.80	1.20	0.80	1.20	0.80	1.20	0.80	5.20		
119	0 1 1 0 1 1 1 0	FL(4)12S	0.30	1.70	0.30	1.70	0.30	1.70	0.30	5.70		
120	1 1 1 0 1 1 1 0	FL(4)12S	0.50	1.50	0.50	1.50	0.50	1.50	0.50	5.50		
121	0 0 0 1 1 1 1 0	FL(4)15S	0.50	1.50	0.50	1.50	0.50	1.50	0.50	8.50		
122	1 0 0 1 1 1 1 0	FL(4)15S	1.00	1.00	1.00	1.00	1.00	1.00	1.00	8.00		
123	0 1 0 1 1 1 1 0	FL(4)15S	0.40	1.60	0.40	1.60	0.40	1.60	0.40	8.60		
124	1 1 0 1 1 1 1 0	FL(4)15S	1.00	2.00	1.00	2.00	1.00	2.00	1.00	5.00		
125	0 0 1 1 1 1 1 0	FL(4)16S	0.50	1.50	0.50	1.50	0.50	1.50	0.50	9.50		
126	1 0 1 1 1 1 1 0	FL(4)16S	1.00	2.00	1.00	2.00	1.00	2.00	1.00	6.00		
127	0 1 1 1 1 1 1 0	FL(4)20S	0.50	1.50	0.50	1.50	0.50	1.50	0.50	13.50		
128	1 1 1 1 1 1 1 0	FL(4)20S	1.00	2.00	1.00	2.00	1.00	2.00	1.00	10.00		
129	0 0 0 0 0 0 1 1	FL(4)20S	1.50	2.00	1.50	2.00	1.50	2.00	1.50	8.00		
130	1 0 0 0 0 0 1 1	FL(5)13S	0.50	1.50	0.50	1.50	0.50	1.50	0.50	1.50	0.50	4.50
131	0 1 0 0 0 0 1 1	FL(5)20S	0.80	1.20	0.80	1.20	0.80	1.20	0.80	1.20	0.80	11.20
132	1 1 0 0 0 0 1 1	FL(5)20S	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	1.00	11.00
133	0 0 1 0 0 0 1 1	FL(5)20S	0.50	1.50	0.50	1.50	0.50	1.50	0.50	1.50	0.50	11.50
134	1 0 1 0 0 0 1 1	FL(6)15S	FL1-6 0.5		EC1-5 1.00		EC6 7.00					
135	0 1 1 0 0 0 1 1	FL(9)10S	FL1-9 0.25		EC1-8 0.25		EC9 5.75					
136	1 1 1 0 0 0 1 1	FL(9)10S	FL1-9 0.20		EC1-8 0.30		EC9 5.80					
137	0 0 0 1 0 0 0 1	FL(9)15S	FL1-9 0.50		EC1-8 0.50		EC9 6.50					
138	1 0 0 1 0 0 0 1	ISO 5S	0.25	0.25								
139	0 1 0 1 0 0 0 1	ISO1S	0.50	0.50								
140	1 1 0 1 0 0 0 1	ISO2S	1.00	1.00								
141	0 0 1 1 0 0 0 1	ISO3S	1.50	1.50								
142	1 0 1 1 0 0 0 1	ISO4S	2.00	2.00								
143	0 1 1 1 0 0 0 1	ISO5S	2.50	2.50								
144	1 1 1 1 0 0 0 1	ISO6S	3.00	3.00								
145	0 0 0 0 1 0 0 1	ISO8S	4.00	4.00								
146	1 0 0 0 1 0 0 1	ISO10S	5.00	5.00								
147	0 1 0 0 1 0 0 1	ISO12S	6.00	6.00								
148	1 1 0 0 1 0 0 1	LFL5S	2.00	3.00								
149	0 0 1 0 1 0 0 1	LFL6S	2.00	4.00								
150	1 0 1 0 1 0 0 1	LFL8S	2.00	6.00								
151	0 1 1 0 1 0 0 1	LFL8S	3.00	5.00								
152	1 1 1 0 1 0 0 1	LFL10S	2.00	8.00								
153	0 0 0 1 1 0 0 1	LFL10S	3.00	7.00								
154	1 0 0 1 1 0 0 1	LFL10S	4.00	6.00								
155	0 1 0 1 1 0 0 1	LFL12S	2.00	10.00								
156	1 1 0 1 1 0 0 1	LFL15S	4.00	11.00								
157	0 0 1 1 1 0 0 1	MO(A)3S	0.50	0.50	1.50	0.50						
158	1 0 1 1 1 0 0 1	MO(A)5S	0.50	0.50	1.50	2.50						
159	0 1 1 1 1 0 0 1	MO(A)6S	0.30	0.60	1.00	4.10						
160	1 1 1 1 1 0 0 1	MO(A)8S	0.80	1.20	2.40	3.60						
161	0 0 0 0 0 1 0 1	MO(A)8S	0.40	0.60	2.00	5.00						
162	1 0 0 0 0 1 0 1	MO(A)8S	1.00	1.00	3.00	3.00						
163	0 1 0 0 0 1 0 1	MO(A)10S	0.50	0.50	1.50	7.50						
164	1 1 0 0 0 1 0 1	MO(A)12S	0.50	0.50	1.50	9.50						
165	0 0 1 0 0 1 0 1	MO(A)15S	0.50	1.50	2.00	11.00						
166	1 0 1 0 0 1 0 1	MO(B)6S	1.50	0.50	0.50	0.50	0.50	0.50	0.50	1.50		
167	0 1 1 0 0 1 0 1	MO(B)15S	1.50	0.50	0.50	0.50	0.50	0.50	0.50	10.50		
168	1 1 1 0 0 1 0 1	MO(F)6S	0.50	0.50	0.50	0.50	1.50	0.50	0.50	1.50		
169	0 0 0 1 0 1 0 1	MO(G)6S	1.50	0.50	1.50	0.50	0.50	1.50	0.50	1.50		
170	1 0 0 1 0 1 0 1	MO(K)6S	1.50	0.50	0.50	0.50	1.50	1.50	0.50	1.50		
171	0 1 0 1 0 1 0 1	MO(L)6S	0.50	0.50	1.50	0.50	0.50	0.50	0.50	1.50		
172	1 1 0 1 0 1 0 1	MO(N)5S	1.50	0.50	0.50	2.50						
173	0 0 1 1 0 1 0 1	MO(N)6S	3.00	1.00	1.00	1.00						
174	1 0 1 1 0 1 0 1	MO(N)10S	6.00	1.00	2.00	1.00						
175	0 1 1 1 0 1 0 1	MO(N)12S	1.50	0.50	0.50	9.50						
176	1 1 1 1 0 1 0 1	MO(N)12S	6.00	2.00	2.00	2.00						
177	0 0 0 0 1 1 0 1	MO(U)5S	0.50	0.50	0.50	0.50	1.50	1.50				
178	1 0 0 0 1 1 0 1	MO(U)10S	0.20	0.80	0.20	0.80	0.60	7.40				

RH SW	1 2 3 4 5 6 7 8	RHYTHM	FL1	EC1	FL2	EC2	FL3	EC3	FL4	EC4	FL5	EC5
179	0 1 0 0 1 1 0 1	MO(U)10S	0.30	0.70	0.30	0.70	0.90	7.10				
180	1 1 0 0 1 1 0 1	MO(U)10S	0.40	0.60	0.40	0.60	1.20	6.80				
181	0 0 1 0 1 1 0 1	MO(U)10S	0.50	0.50	0.50	0.50	1.50	6.50				
182	1 0 1 0 1 1 0 1	MO(U)10S	0.50	0.50	0.50	0.50	2.00	6.00				
183	0 1 1 0 1 1 0 1	MO(U)15S	0.45	0.45	0.45	0.45	1.35	11.85				
184	1 1 1 0 1 1 0 1	MO(U)15S	0.60	0.30	0.60	0.30	1.50	11.70				
185	0 0 0 1 1 1 0 1	MO(U)15S	0.50	0.50	0.50	0.50	1.50	11.50				
186	1 0 0 1 1 1 0 1	MO(U)15S	0.60	0.30	0.60	0.30	1.40	11.80				
187	0 1 0 1 1 1 0 1	MO(U)15S	0.70	0.50	0.70	0.50	1.90	10.70				
188	1 1 0 1 1 1 0 1	MO(U)15S	0.40	0.50	0.40	0.50	1.20	12.00				
189	0 0 1 1 1 1 0 1	MO(V)6S	0.50	0.50	0.50	0.50	0.50	0.50	1.50	1.50		
190	1 0 1 1 1 1 0 1	MO(W)6S	0.50	0.50	1.50	0.50	1.50	1.50				
191	0 1 1 1 1 1 0 1	OC3S	2.50	0.50								
192	1 1 1 1 1 1 0 1	OC3S	2.00	1.00								
193	0 0 0 0 0 0 1 1	OC3S	2.25	0.75								
194	1 0 0 0 0 0 1 1	OC4S	3.00	1.00								
195	0 1 0 0 0 0 1 1	OC5S	3.00	2.00								
196	1 1 0 0 0 0 1 1	OC5S	4.00	1.00								
197	0 0 1 0 0 0 1 1	OC6S	4.50	1.50								
198	1 0 1 0 0 0 1 1	OC6S	5.00	1.00								
199	0 1 1 0 0 0 1 1	OC6S	4.00	2.00								
200	1 1 1 0 0 0 1 1	OC8S	6.00	2.00								
201	0 0 0 1 0 0 1 1	OC10S	7.50	2.50								
202	1 0 0 1 0 0 1 1	OC10S	8.00	2.00								
203	0 1 0 1 0 0 1 1	OC14S	11.00	3.00								
204	1 1 0 1 0 0 1 1	OC(2)9S	5.00	1.00	2.00	1.00						
205	0 0 1 1 0 0 1 1	OC(3)12S	5.00	1.00	2.00	1.00	2.00	1.00				
206	1 0 1 1 0 0 1 1	OC(3)15S	5.00	2.00	2.00	2.00	2.00	2.00				
207	0 1 1 1 0 0 1 1	Q1S	0.20	0.80								
208	1 1 1 1 0 0 1 1	Q1S	0.30	0.70								
209	0 0 0 0 1 0 1 1	Q1S	0.40	0.60								
210	1 0 0 0 1 0 1 1	Q1S	0.10	0.90								
211	0 1 0 0 1 0 1 1	Q1.2S	0.30	0.90								
212	1 1 0 0 1 0 1 1	Q(2)5S	0.30	0.70	0.30	3.70						
213	0 0 1 0 1 0 1 1	Q(2)6S	0.30	0.70	0.30	4.70						
214	1 0 1 0 1 0 1 1	Q(2)10S	0.50	1.50	0.50	7.50						
215	0 1 1 0 1 0 1 1	Q(3)5S	0.30	0.70	0.30	0.70	0.30	2.70				
216	1 1 1 0 1 0 1 1	Q(3)10S	0.30	0.70	0.30	0.70	0.30	7.70				
217	0 0 0 1 1 0 1 1	Q(3)10S	0.60	0.60	0.60	0.60	0.60	7.00				
218	1 0 0 1 1 0 1 1	Q(3)10S	0.50	0.50	0.50	0.50	0.50	7.50				
219	0 1 0 1 1 0 1 1	Q(4)6S	0.40	0.60	0.40	0.60	0.40	0.60	0.40	2.60		
220	1 1 0 1 1 0 1 1	Q(4)10S	0.30	0.70	0.30	0.70	0.30	0.70	0.30	6.70		
221	0 0 1 1 1 0 1 1	Q(4)12S	0.30	0.70	0.30	0.70	0.30	0.70	0.30	8.70		
222	1 0 1 1 1 0 1 1	Q(4)15S	0.35	0.70	0.35	0.70	0.35	0.70	0.35	11.50		
223	0 1 1 1 1 0 1 1	Q(4)20S	0.50	0.50	0.50	0.50	0.50	0.50	0.50	16.50		
224	1 1 1 1 1 0 1 1	Q(5)7S	0.30	0.70	0.30	0.70	0.30	0.70	0.30	0.70	0.30	2.70
225	0 0 0 0 0 1 1 1	Q(5)10S	0.30	0.70	0.30	0.70	0.30	0.70	0.30	0.70	0.30	5.70
226	1 0 0 0 0 1 1 1	Q(6)10S	FL1-6 0.30		EC1-5 0.70		EC6 4.70					
227	0 1 0 0 0 1 1 1	Q(9)15S	FL1-9 0.30		EC1-8 0.70		EC9 6.70					
228	1 1 0 0 0 1 1 1	Q(9)15S	FL1-9 0.50		EC1-8 0.50		EC9 6.50					
229	0 0 1 0 0 1 1 1	Q(12)15S	FL1-12 0.20		EC1-11 0.80		EC12 3.80					
230	1 0 1 0 0 1 1 1	Q(6)+LFL15S	FL1-6 0.30		EC1-6 0.70		FL7 2.00		EC7 7.00			
231	0 1 1 0 0 1 1 1	Q(6)+LFL15S	FL1-6 0.30		EC1-6 0.70		FL7 3.00		EC7 6.00			
232	1 1 1 0 0 1 1 1	Q(6)+LFL15S	FL1-6 0.50		EC1-6 0.50		FL7 2.00		EC7 7.00			
233	0 0 0 1 0 1 1 1	Q(6)+LFL15S	FL1-6 0.50		EC1-6 0.50		FL7 3.00		EC7 6.00			
234	1 0 0 1 0 1 1 1	VQ0.5S	0.20	0.30								
235	0 1 0 1 0 1 1 1	VQ0.6S	0.30	0.30								
236	1 1 0 1 0 1 1 1	VQ(3)5S	0.20	0.30	0.20	0.30	0.20	3.80				
237	0 0 1 1 0 1 1 1	VQ(3)5S	0.30	0.30	0.30	0.30	0.30	3.50				
238	1 0 1 1 0 1 1 1	VQ(3)5S	0.25	0.25	0.25	0.25	0.25	3.75				
239	0 1 1 1 0 1 1 1	VQ(3)5S	0.15	0.45	0.15	0.45	0.15	3.65				
240	1 1 1 1 0 1 1 1	VQ(9)10S	FL1-9 0.20		EC1-8 0.30		EC9 5.80					
241	0 0 0 0 1 1 1 1	VQ(9)10S	FL1-9 0.30		EC1-8 0.30		EC9 4.90					
242	1 0 0 0 1 1 1 1	VQ(9)10S	FL1-9 0.25		EC1-8 0.25		EC9 5.75					
243	0 1 0 0 1 1 1 1	VQ(6)+LFL10S	FL1-6 0.20		EC1-6 0.30		FL7 2.00		EC7 5.00			
244	1 1 0 0 1 1 1 1	VQ(6)+LFL10S	FL1-6 0.30		EC1-6 0.30		FL7 2.00		EC7 4.40			
245	0 0 1 0 1 1 1 1	VQ(6)+LFL10S	FL1-6 0.25		EC1-6 0.25		FL7 2.00		EC7 5.00			
246	1 0 1 0 1 1 1 1	VQ(6)+LFL10S	FL1-6 0.15		EC1-6 0.45		FL7 2.00		EC7 4.40			
247	0 1 1 0 1 1 1 1	FL 2.5 (1.0)	1.00	1.50								
248	1 1 1 0 1 1 1 1	FL 5 (.6)	0.60	4.40								
249	0 0 0 1 1 1 1 1	FL 10 (.6)	0.60	9.40								
250	1 0 0 1 1 1 1 1	FL 10 (3.0)	3.00	7.00								
251	0 1 0 1 1 1 1 1	FL (2) 5	0.20	0.80	0.20	3.80						
252	1 1 0 1 1 1 1 1	FL (3) 10	0.40	0.40	0.40	0.40	0.40	8.00				
253	0 0 1 1 1 1 1 1	BLANK										
254	1 0 1 1 1 1 1 1	BLANK										
255	0 1 1 1 1 1 1 1	BLANK										
256	1 1 1 1 1 1 1 1	FIXED										

RHYTHM SET 505

